


[CHECK POINT OF POWER ROLL GATE MOTOR UP/DOWN]

1. Try to run it by detecting the Sensor 1 or 2 with the sensor check bracket.
2. Check the direction of the motor (+/-) and verify if the motor sprocket is loose.
3. Verify if the wire connectors of Sensor 1 (UP) and Sensor 2 (DOWN) have been switched.
4. Check the wire connection between Sensor 1 (UP) and Sensor 2 (DOWN).



5. Review Sensor 1 (UP) and Sensor 2 (DOWN) in the TEST MODE (BALL STOPPER MOTOR TEST). Try to trigger the sensors manually.
6. If the solution is still not resolved, replace the I/O BOARD.