



If the setscrew is missing, please follow instructions below.



1: Remove Lower Cover Side Bracket



2: Connector PCB is towards player side of controller

3: Note the marking on PCB showing north on magnet towards player side of controller



4: Black mark on magnet denotes the north pole of the magnet. The black mark should be towards the player side of the controller as shown.

